

VERY Portable Graphic Display & Exhibition Stand Systems and Banner & Literature Stands  
 promoting Brands & Corporations worldwide

## Graphics Guide

600/800/850/1000/1200mm



1760/2150mm

140mm

### Banner Rail

Whichever style you prefer



Screw-on  
**12mm**  
*Optional*



Snap-on  
**16mm**



### Graphic Dimensions

Banner cut size  
 2290mm or less High  
 (standard)  
 x 800/850/1000/  
 1200mm

1900mm or less High  
 (standard)  
 x 600mm

Visible Size  
 2150mm x Width  
 1760mm x 600mm

2500 or less with pole  
 extension

Design your banner at  
 a visible print size of  
**2150mm high Minus** your  
 choice of rail, on a total  
 banner height of 2290mm,  
 at standard display height.

### System Components

Stand  
 Pole(s)  
 Rail  
 Carry Bag

Users can be assisted in avoiding damage to graphic edges when using the stand, by reducing the width of the mounted banner by 1cm to minimise contact with stand ends whilst extending and retracting the banner. Careful users do not need this precaution, but careless ones will benefit from it. Thin or slippery banners may need added thickness at the top achieved by adding a strip of masking tape or similar to the back of the banner before fitting the snap-on rail.

VERY Portable Graphic Display & Exhibition Stand Systems and Banner & Literature Stands  
 promoting Brands & Corporations worldwide

## Graphics Guide



### Graphic Dimensions

Banner cut size  
 2290mm High (standard)  
 x 1500/2000mm

2490mm High (standard)  
 x 2400/2900mm

Visible Size  
 2150mm or less x Width  
 2400mm or less x Width

Height can be reduced by  
 cutting pole

Design your banner at  
 a visible print size of  
**2150mm high Minus** your  
 choice of rail, on a total  
 banner height of 2290mm,  
 at standard display height.

### System Components

Stand  
 Pole(s)  
 Rail  
 Carry Bag

Users can be assisted in avoiding damage to graphic edges when using the stand, by reducing the width of the mounted banner by 1cm to minimise contact with stand ends whilst extending and retracting the banner. Careful users do not need this precaution, but careless ones will benefit from it. Thin or slippery banners may need added thickness at the top achieved by adding a strip of masking tape or similar to the back of the banner before fitting the snap-on rail.



1. Assemble pole by connecting the attached sections together. Do NOT twist the pole sections once assembled as this can jam them together.



2. Pull out graphic from the base and attach the rail to the top of the pole. Always be careful when raising or lowering a banner that you do not scrape the banner edge against the stand end-plates. Simply keep the banner away from the end-plates to avoid this by guiding it centrally.



3. Place foot on base for stability and while holding the pole firmly, push the pole and graphic upwards.




4. When the graphic and pole are fully extended and in an upright position, place the bottom of the pole in the centre hole of the base. Make sure it goes all the way down to the bottom of the hole. Then remove your foot from the base and wipe it clean please.

Alternatively, you can fit the pole into the base first, then use it to lean the stand towards you as you raise the banner and lift the rail to the top of the pole.

Both techniques can be used by people of any height.



5. To display the second graphic, on a twin, stand facing the pole and pull out the second graphic from the base.



6. Lean the unit towards you and attach the rail into the top of the pole. Hold the banners themselves to raise the stand into an upright position.

If your stand has swing-out feet, they should not be swung-out until the banner(s) is up, as they will otherwise prevent you from leaning the stand towards you.

## System Components

Stand with graphic(s) - 1  
 Pole - 1 or more

## Note:

Wider stands with more than one pole are more easily assembled by two people.

**All of our retractable banner stands work in the same way.**

## Important Information

Always be careful when raising or lowering a banner that you do not scrape the banner edge against the stand end-plates. Simply keep the banner away from the end-plates to avoid this by guiding it centrally.

Always keep hold of the rail until it is firmly attached to the pole, as the banner is under constant tension from the motor.